PL530E Panel Layout

Power Input Header

Temp Good LED Indicator

GREEN Temp Good

Power ON/OFF Slide Switch

Laser Beam Output window

Laser Enable Push Button

Optional TEC Temp Adjust Pot

TEC Temp Measure Point

Heater Current Adjust Pot

KH Heater Current Measure Point (mA = 2 x mV)

Laser Current Adjust Pot

Laser Enable LED Indicator Green Enabled

+5VDC for Optional Shutter Power

KL Laser Current Measure Point (mA = 2 x mV)