PL530EK Panel Layout

Laser
Enable/Disable
LED
Indicator
GREEN
Laser Enabled

Laser Current
Adjust Pot
Inside

Heater Current
Adjust Pot
Inside

Shutter Control
Switch Jack

Laser Enable
Pushbutton
Switch

KL
Measure Laser
Current
mA = mV x 2

KL
Measure
Heater Current
mA = mV x 2

DANGER
VISIBLE AND/OR INVISIBLE
RADIATION. AVOID
DIRECT EXPOSURE TO BEAM
CLASS 3b LASER

Power ON/OFF
Switch

Power Jack
+5VDC
Center Positive

Laser
Power Output
window

Shutter
ON/OFF Switch

Temp Good
LED
Indicator

GREEN
Temp Good

Sliding
Cover