

## **Power Drive Controls**

1846 Santo Domingo  
Camarillo, CA 93012  
U. S. A.

[www.pdcontrol.com](http://www.pdcontrol.com)

email: dashengpan@yahoo.com

---

### **Operation Notes for L1060 Laser Module**

1. Refer to the L1060 Layout drawing
2. Connect +5Vdc (2 Amp) to power connector J2, positive at pin 1.
3. S1 is a 3 position slide switch, pre-set to power off at position 1.  
Slide the switch to position 2 to turn on the board power and TEC temperature controller.  
Keep the switch at the position 2 and watch the LED changing the color from RED to GREEN in few seconds.  
When the LED is GREEN, slide the switch to position 3 to enable the laser and heater power.
4. POT\_1 is a multi-turn potentiometer used for the wavelength tuning.