

Laser Current
Adjust Pot

Blue Laser Module Back Panel

Laser Enable
Pushbutton
Switch


LED Power/Temp
Indicator
RED: Power ON
GREEN: Temp Good

Power Jack
+5V Input



Sliding Shutter

Laser Beam
Output
window



Blue Laser Module Front Panel