


R650EFB Laser Panel Layout



Laser Beam
Output
Window

Shutter
Open/Close
Switch

Shutter Power
Switch

Laser Enable
Switch

Temp Good
LED

Green = Temp
Good

Laser Tune
Potentiometer
POT



Power ON/OFF
Switch S1

+5VDC Input Connector
Jack