

Operation Notes for Red 638 nm / 650 nm SLM Laser

Module R638ECDL / R650ECDL

(Rev. 8-2-26)

Refer to the “Panel Layout” drawing for the basic laser Enable/Disable and Shutter Open/Close push-button controls.

For the instructions on the other three control models, refer to the document “Operation Procedures for Green SLM PL530 Laser Source” at the following link:

<http://www.pdcontrol.com/PL530E32/Operation-Procedures-for-PL530E32-3.pdf>